

DOUBLE BED FABRICS: CHANGE COL 1, COL 2 EVERY 2 ROWS UNLESS OTHERWISE DIRECTED

lock setting	BACK	FRONT	BACK BED PUSHERS (front in use always in pattern area)
	N	LX	TECH 138
	N	LX	TECH 137
	N	LX	ALL ONE COLOR
	N	LX	TWO COLOR
	N	LX	TECH 139 1ST AND LAST UP, ALL OTHERS DOWN
	N	LX	TECH 179
	N	LX	TECH 180
	N	LX	ALL ONE COLOR
	N	LX	TWO COLOR
	CX	LX	
	BX <->	LX	ALT PUSHERS UP, DOWN
	BX <-	LX	ALT PUSHERS UP, DOWN
	DX <-	LX	ALT PUSHERS UP, DOWN
	BX <->	LX	ALT PUSHERS, 2UP, 2DOWN
	BX <-	LX	ALT PUSHERS, 2UP, 2DOWN
	BX <-	LX	ALT PUSHERS, 2UP, 2DOWN
		BX 0	2 R COL 1
			2 R COL 2
	BX <-	LX	1ST AND LAST DOWN, ALL OTHERS UP
	BX <-	LX	1ST AND LAST UP, ALL OTHERS DOWN
	AX <->	LX	ALT PUSHERS UP, DOWN
	AX <->	LX	ALT PUSHERS UP, DOWN
		N <->	2 R COL 1
			2 R COL 2
	AX <-	LX	ALT PUSHERS UP, DOWN
	AX <-	LX	ALT PUSHERS UP, DOWN
		AX 0	2 RCOL 1
			2 R COL 2
	AX <-	LX	ALT PUSHERS 2UP, 2 DOWN
		AX 0	2 RCOL 1
			2 R COL 2
	N	KX	
	N	HX	TECH 184
	BX <->	HX	TECH 184 ALT PUSHERS UP, DOWN
	BX <-	HX	TECH 184 ALT PUSHERS UP, DOWN
	BX <-	HX	TECH 184 1ST AND LAST UP, ALL OTHERS DOWN
	BX <-	HX	TECH 184 1ST AND LAST DOWN, ALL OTHERS UP
	N	KX	TECH 186
	N	KX	ALL ONE COLOR
	N	KX	2 COL
	FX	KX	1ST AND LAST UP, ALL OTHERS DOWN
	AX	KX	1ST AND LAST UP, ALL OTHERS DOWN
		N	ALL ONE COLOR
	AX	KX	1ST AND LAST UP, ALL OTHERS DOWN
		N	
	N	KX	2 R COL 1
		N	2 R COL 2
	N	DX	TECH 185
	N	DX	ALL ONE COLOR
	N	KX	2 COLOR
	N	KX	TECH 130
	N	KX	TECH 137 OR 138
	N	EX	TECH 137 OR 138
	N	KX	TECH 167
	AX	KX	TECH 145 1ST AND LAST UP, ALL OTHERS DOWN
		N	2 R COL 1, 2 R COL 2
	AX	KX	TECH 141 1ST AND LAST UP, ALL OTHERS DOWN
		N	4 R COL 1, 2 R COL 2,

CHANGE BACK LOCK TO N WHEN ALL PUSHERS ARE UP ON THE FB

TECH 179 WILL KNIT EACH DESIGN ROW OF A FAIR ISLE PATTERN ONLY ONCE- THIS TECHNIQUE MAY BE USED BOTH SINGLE AND DOUBLE BED, PRODUCES FABRIC SIMILAR TO THAT CREATED BY JAPANESE MACHINES; FOR 3 AND FOUR COLORS A READER TECHNIQUE NEEDS TO BE ENTERED WITH THE CARD READER